



FOREVER REDWOOD







From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

ASSEMBLY INSTRUCTIONS FOR THE **HOT TUB ENCLOSURE KITS / HOT TUB PAVILION**















CONTENT OF BOXES			
Qty.	Description	Drawing	No.
4	Posts		1
2	Window Panels		2
2	Frames with Knee Braces		3
2	Short Roof Frames		4
2	Long Roof Frames		5
Quantity will vary.	Roof Panels		6

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.














CONTENT OF BOXES			
Qty.	Description	Drawing	No.
1	Skylight If ordered.		7
Quantity will vary.	Roof Boards		8
Quantity will vary.	Roof Trims		9
4	Corner Roof Trims		10
4	Boots		11
4	Angles		12
4	Metal Plaques		13
4	Standard, Gale Wind or Hurricane Anchors Bases. If ordered.		14
		 	

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.






HARDWARE LIST		
Description	Drawing	No.
1/2" X 4" Anchor Bolts (To attach the anchor bases to the ground).		A
5/16" X 3" Lag Bolts (To attach the anchor bases to the posts / To attach the windows panels and the frames with knee braces to the posts / To attach the angles and the metal plaques to the roof frames).		B
5/16" X 4" Lag Bolts (To attach the roof frames to the window panels and to the frames with knee braces)		C
3/8" X 6" Lag Bolts (To attach the roof frames together / To attach the roof panels to the roof frames).		D
5/16" X 3 1/2" Bolts (To attach the roof panels to the skylight).		E
2" Deck Screws (To attach the roof bards to the roof panels).		F
3" Deck Screws (To attach the metal plaques to the roof frames. / To attach the roof trims and the corner roof trims to the roof boards. / To attach the boots to the posts).		G
4" Deck Screws (To attach the roof trims and the corner roof trims to the roof boards).		H
5/16" X 4" Bolts (To attach the roof panels to the metal plaques).		I
Washers		J
Nuts		K

Note: Dimensions of your hardware will vary depending on size.






DESCRIPTION	No
Post	1
Window Panels	2
Frames with Knee Braces	3
Short Roof Frames	4
Long Roof Frames	5
Roof Panels	6
Skylight	7
Roof Boards	8
Roof Trims	9
Corner Roof Trims	10
Boots	11
Angles	12
Metal Plaques	13
Anchors Bases.	14


Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.

NOTE: In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


Step 1: Install the anchor base (14) with $\frac{1}{2}$ " X 4" anchor bolts (A) or lag bolts. Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases (14). Drill a $\phi \frac{1}{4}$ " hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a $\frac{5}{16}$ " X 3" lag bolts (B) to attach each post (1) to its respective anchor base (14).




Step 2: Attach the window panels (2) to the posts with 5/16" x 3" lag bolts (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 3: Use 5/16" x 3" lag bolts (B) to attach the frames with knee braces (3) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 4: Attach the roof frames (4,5) to the window panels and to the frames with knee braces, use 5/16" x 4" lag bolts (C). The roof frames will be attached together with 3/8" x 6" lag bolts (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.





Step 5: Use 5/16" x 3" lag bolts (B) to attach the angles (12). After that, use 5/16" x 3" lag bolts (B) and 3" deck screws (G) to attach the metal plaques (13) to the roof frames.



Step 6: Remove the lower tables from the roof panels (6), as shown below.




Step 7: Support the skylight on a base at the height indicated in the drawings. Use a ladder or a scaffolding, to facilitate the installation of the skylight and the roof panels.




Step 8: Attach the roof panels (6) to the skylight (7) with 5 1/6" x 3 1/2" bolts (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.

Step 8.1: Attach the roof panels (6) to the metal plaques with 5/16" x 4" bolts (I).

Step 8.2: Attach the roof panels (6) to the roof frames with 3/8" X 6" lag bolts (D).




Step 8




5/16" X 3 1/2" Bolts

Step 8.1




5/16" X 4" Bolts

Step 8.2




3/8" X 6" Lag Bolts


Step 9: Now place the tables that were removed from the roof panels. After that, put exterior clear silicone on the perimeter of the skylight.




Step 10: First, measure the roof panels. After that, cut the #30 Felt Roof Deck Protection to those measures. Use staples to attach the #30 Felt Roof Deck Protection to the roof panels.




Step 11: Use 2'' deck screws (**F**) to attach the roof boards (**8**) to the roof panels. Put the boards from the bottom to the top, the overlapping between these boards it will be of $\frac{3}{4}$ '' . After that, put exterior clear silicone on the roof boards joints. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 12: Use 3'' deck screws (**G**) and 4'' deck screws (**H**) to attach the roof trims (**9**) and the corner roof trims (**10**) to the roof boards. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 13: Finally, attach the boots (11) to the posts with 3" deck screws (G).





This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.